



Coding manual: for awning professionals

Hand transmitter cM100 K1 for all receiver types from euroMOT

(Document Nr.992150-3-ba / Release: 3.00EN*) Art. No. 490150


GB

*With this document version, all earlier versions lose their validity. euroMOT endeavours to improve these documents constantly. However, we assume no liability for any existing errors or their consequences.

The **cM100 K1 channel hand transmitter** is suitable for the commandMot series, solvento series and powerFlex radio-controlled motors. It can also be used to control components of the BUS system, using the BuBu-fk radio node. The radio frequency is 433.92 MHz.



1.0 Description:



Channel 1



extend retract


- LED lights when a button is pressed, if the battery is still good. If it no longer lights, check or change the battery.
- The battery rating is: 12 V (type A23). Used batteries must be disposed of in compliance with national regulations.



- Die The code switches for coding the hand transmitter are underneath the battery cover.

2.0 Coding the hand transmitter

ENTER THE CODE AND WRITE IT DOWN!



- Set a new individual code (code switches 1 – 7).
Careful: At least two coding switches must be set!
 Enter this new code into the list on the left.

We hereby declare that the radio devices of the product series commandMot comply with the fundamental requirements and relevant regulations of Directive 1999/5/EC and may be employed in all states of the EU and Switzerland without registration. They may only be employed for controlling awnings. Declaration of conformity under www.euromot.ch.